

Configuring XHouse IOT GSM

To load APP on mobile

1. Power on GSM. Lights come on. Press RESET **twice**. Red LED comes on solid.
Note: If you already have the XHouse IOT APP for other home automation, please use your current login info.
2. Open camera on mobile phone and hold over QR code in instruction sheet page 9 or use QR code below.
3. Press link "giigleiot.net".
4. Select either IOS download or Android download.
5. Get or open APP in APP Store.
6. Press – "Allow All Permissions".
7. Select "Asia" (or any area but China). Press confirm.
8. Set APP up – Press "Sign up".
9. Enter Email – Press.
10. Check your email inbox for Code.
11. Enter Code.
12. Select your own password then confirm password.
13. Click "Sign Up".
14. Login and "Allow Permissions".
15. To add a device click "+" in top RH side of screen.
16. Add device – allow access to camera.
17. Select 4G Remote Switch.
18. Scan to add – Use QR code on back of GSM.
19. Select swing gate.
20. Confirm.
21. Press "Tap to Operate" to open gate.
22. To add authorized numbers to gain access via phone No – max 300 users, click gear on top RH corner. Select authorized numbers. Click "+" to add.

To Control GSM using SMS without APP

<u>Function:</u>	<u>Description:</u>	<u>Enter:</u>	<u>Example</u>
1. To Change Password:	Default password: 1234	old passw'd+P+new passw'd+##	1234P2345#
2. Add new client:	EG. Add number 0407 123 456	passw'd+A+new number+##	1234A0407123456#
3. Delete User:	EG. Delete 0407 123 456	passw'd+D+number+##	1234D0407123456#
4. Reset:	Reset Unit	passw'd+R+##	1234R#
5. Open/Close Gate:	Text gate to Open/Close	Text *#01	*#01 or 11*#01

